

SERVICE MANUAL INFORMATION

Group:	SERVICE MANUAL UPDATE
Bulletin No:	SB-16-009
Issue Date:	4-11-2016

Subject: CORRECTION OF WORKSHOP MANUAL FOR HINO CONVENTIONAL **Correction of the Electrical Wiring Diagram**

RELEVANT MODEL: 17MY Conventional Trucks

The following is to inform you of the above caption. This service data should be attached to the relevant pages of the workshop manuals for maintenance and to use for servicing.

OVERVIEW:

Correction of the electrical wiring diagram.

Model	MANUAL NO.	CHAPTER	PAGE
2017 MY	S1-UNAE13A	ELECTRIC WIRE	EL02-46, EL02-83




A Toyota Group Company

SERVICE MANUAL INFORMATION

Group:	SERVICE MANUAL UPDATE
Bulletin No:	SB-16-009
Issue Date:	4-11-2016

EL02-46

ELECTRIC WIRE



SAPH12Z080200050

L STOP AND TURN LIGHT CIRCUIT

- | | |
|-----------------------------|-------------------------------------|
| 1 Stop and turn controller | 10 Rear combination light LH |
| 2 Wiper and retarder switch | 11 Side turn light LH (For Fender) |
| 3 Light and turn switch | 12 Front turn light LH |
| 4 Common rail J/C No. 2 | 13 Front turn light RH |
| 5 J/C ground | 14 Side turn light RH (For Fender) |
| 6 Stop light relay | 15 Rear combination light RH |
| 7 Common rail J/C No. 1 | 16 Back-up light switch |
| 8 Stop light switch | 17 Back-up buzzer |
| 9 STP TRANS diode | 18 Spare chassis (For Power supply) |




A Toyota Group Company

SERVICE MANUAL INFORMATION

Group:	SERVICE MANUAL UPDATE
Bulletin No:	SB-16-009
Issue Date:	4-11-2016

ELECTRIC WIRE

EL02-47



SAPH12Z080200060




A Toyota Group Company

SERVICE MANUAL INFORMATION

Group:	SERVICE MANUAL UPDATE
Bulletin No:	SB-16-009
Issue Date:	4-11-2016

EL02-82

ELECTRIC WIRE



SAPH12Z080200095

AE COMMON RAIL CIRCUIT-7: DPR: DIESEL THROTTLE

- | | |
|--|--|
| 1 DPR refresh switch | 10 Common rail J/C 2 |
| 2 J/C signal | 11 Common rail actuator power relay |
| 3 Exhaust temperature sensor at ATC | 12 Diesel throttle |
| 4 Exhaust temperature sensor at DOC inlet | 13 Engine coolant temperature sensor 1 |
| 5 Exhaust temperature sensor at DOC outlet | 14 Air flow sensor |
| 6 Exhaust temperature sensor at DPR outlet | 15 Exhaust aftertreatment fuel pressure sensor |
| 7 Exhaust gas pressure sensor | 16 Fuel injector |
| 8 PTO accelerator sensor | 17 VNT controller |
| 9 Engine ECU | 18 Boost pressure sensor |




A Toyota Group Company

SERVICE MANUAL INFORMATION

Group:	SERVICE MANUAL UPDATE
Bulletin No:	SB-16-009
Issue Date:	4-11-2016

ELECTRIC WIRE

EL02-83



SAP112Z080200006

- 19 Fuel cut valve
- 20 PM sensor



A Toyota Group Company