




**2018**

**Pre-Delivery Inspection  
Technician Reference Document**





## Table of Contents

# Technician Reference Document

---

### Technician Reference Document Overview

The Pre-Delivery Inspection Technician Reference Document is designed to be a resource used in hand with the Pre-Delivery Inspection Checklist (PDI). The PDI Checklist has been simplified to make the process more efficient, and in doing so, this document has been created to be used as a reference for checklist items that may have additional information. On the PDI Checklist, you find that certain items have been notated with an asterisk symbol (\*), this lets you know that additional information can be found in this Technician Reference Document.

Below you will find a list of each model, with the page numbers to their left. After navigating to the desired page, you will notice each model page is formatted similarly to the PDI Checklists. After each section title is the original checklist item, followed by any additional information specific to that model.

---

### Table of Contents

3-4      A4/S4/A4 allroad





## A4/S4/A4 allroad

# Technician Reference Document

### Vehicle Preparation

#### ▶ Deactivate vehicle transport mode

**This step must be performed with the ignition on/engine off or the 03 brake module may remain in transport mode. See TSB 2042954 for resolution.**

Deactivate vehicle transport mode (via Special functions > PDI service > 19-Transport mode activating/deactivating.)

#### ▶ Set adaption channel to enable CD Ripping (if equipped with NAV)\*

Using ODIS, right click the 5F-Information control unit 1, and select "Guided Functions > 5F-Adaptations > Storage of music activating/deactivating (option 2) and when prompted for the Optical drive, choose option 1 for "On"

#### ▶ Set service reminder

via Special functions -> PDI service -> 17-PDI-resetting SRI at PDI, counter reset, etc

#### ▶ Perform any open campaigns

Follow instructions listed in campaign documentation

### Under the Hood Inspection

#### ▶ Check battery clamps for proper torque

Re-torque if required

#### ▶ Perform a battery test

Perform the A-battery test for new batteries using GFF in ODIS Diagnosis -> Special functions -> PDI service. Select option 2, the battery test for new batteries as part of the pre-delivery inspection and act according to the test result (ok, recharge, replace). Ensure diagnosis log is uploaded to the GFF paperless server by selecting "ok" when tester wants to send the current generated diagnosis protocol online. (Note: Do not use Guided Function. The diagnosis log will not be uploaded to GFF paperless)

#### ▶ Check engine oil level

Fill oil to the max level when the vehicle is at operating temperature

### Exterior

#### ▶ Check all key buttons and features

Check functionality of all keys. Verify vehicle starts and runs with all keys and the start/stop button. Verify all doors and trunk remotely lock/unlock with all keys, including all door handle sensors with Advanced Key (if equipped)

### Trunk Inspection

#### ▶ Install wheel bolt cover removal tool from PDI kit into trunk tool kit

Install wheel bolt cover removal tool from PDI kit and wheel lock key (if applicable) into trunk tool kit

#### ▶ Set spare tire pressure

See separate "2018 Normal Load Condition Tire Pressure Table" posted on ServiceNet

### Interior

#### ▶ Check operation of window, lock, and seat controls

Check operation of all switches: Locks, windows, seat adjustment, heated seats (if equipped) and child safety features

#### ▶ Inspect mirrors for proper operation

Inspect folding, adjustments, right side tilt in reverse, heating

#### ▶ Check rear view mirror operation

Check self-dimming function/lighting

#### ▶ Verify proper operation of climate control

Ensure proper heating and A/C cooling and open all panel vents for all zones

#### ▶ Inspect operation of all power outlets

Inspect operation of front outlet, aux. outlet under armrest, and rear outlets

#### ▶ Check panoramic sunroof and sunshade operation

Verify open/close/vent/deflector at edge and sunshade operation

### Settings

#### ▶ Verify and set language and Measurement Units

This can be changed in the Settings menu by going to Menu > Vehicle > Vehicle settings

#### ▶ Verify Speech dialog system is operating

Press the "Talk" button and verify several commands

#### ▶ Set "Entertain. Fad." in Parking aid to Medium

Via "Menu->Vehicle->Left Option->Driver Assistance->Parking Aid"

#### ▶ Load Onboard Video Tutorials

Load Onboard Video Tutorials > Turn ignition on > Insert the Onboard DVD into the DVD Drive > Select Menu > Vehicle > Left Option > Vehicle Settings > Owner's manual and with the CD/DVD inserted select "Yes" to start the update > Turn off ignition to start update (the update will take approx. 5 minutes) > Once completed, remove the disk and place back into the case for the next vehicle



## A4/S4/A4 allroad

# Technician Reference Document

### Settings (continued)

- ▶ **Set dealership location in navigation (if equipped)**  
Set dealership location for following back to dealership during road test
- ▶ **Turn off Manual Speed Warning**  
This can be changed in the Driver Assistance settings by going to Menu > Vehicle > Driver Assistance > Speed Warning > Manual->Select Off

### Media / Radio / SAT

- ▶ **Verify HD Radio is turned "off"**  
This can be found in the Radio/Settings Menu

### Audi connect (USA ONLY) (if equipped)

- ▶ **Verify Audi connect Information Packet is present (if equipped)**  
Verify Audi connect Information Packet is present, including Audi brochure, AT&T brochure, AT&T Terms & Conditions (T&C) (if applicable)
- ▶ **Verify system connects to mobile network (if equipped).**  
Review TSB 2042942 for additional information  
Make sure the system fully connects to the wireless network (LTE symbol with service bars)(only applies if in an AT&T service area)
- ▶ **Turn on the wireless network (if equipped)**  
Ensure the wireless network is turned on (Telephone > Options > Wi-Fi options > Wi-Fi Mode "Hotspot")
- ▶ **Check Wi-Fi hotspot Visibility. No data available at PDI (if equipped)**  
Check Wi-Fi hotspot functionality is enabled and verify the Access point (SSID) is set to "Audi\_MMI\_XXXX," where XXXX is the last four digits of VIN. via Telephone > Options > Wi-Fi options > Wi-Fi Mode "Hotspot" > Hotspot settings > Access point (SSID)
- ▶ **Enable Google Earth (if equipped)**  
Enable Google Earth in the Navigation > Map Settings and verify the white Google logo appears in the bottom right hand corner of the MMI screen

### On-Hoist Inspection

- ▶ **Perform a coolant reservoir cap pressure test**  
via ELSA -> Enter VIN # -> Repair manual Engine -> 4-Cylinder Direct Injection 1.8L; 2.0L 4V TFSI Engine (Generation III) -> 19 Cooling System -> Coolant System/Coolant -> Cooling System, Checking for Leaks -> Pressure Relief Valve in Cap, Checking. Only the procedure "Pressure Relief Valve in Cap, Checking" should be performed in the document Cooling System, Checking for Leaks
- ▶ **Inspect wheel bolts for proper torque**  
Use torque wrench to verify
- ▶ **Install wheel bolt covers and center caps as supplied**  
Wheel bolt covers and center caps can be found in the PDI kit
- ▶ **Set and store tire pressures for either sold vehicle OR stock inventory vehicle**  
If a known "sold" unit, set to appropriate Normal Load Condition. See separate "2018 Normal Load Condition Tire Pressure Table" posted on ServiceNet. If going to stock, set to maximum recommended tire pressures listed on the B-pillar doorjamb, and store tire pressure values in Car/System menu

### Driving Performance

- ▶ **Verify engine performance and acceleration**  
Listen for abnormal noise/vibrations
- ▶ **Test drive vehicle applying brakes several times**  
Apply brakes at least 4 times at 20 mph (35 km/h) to clean brake rotors. Check for abnormal noise/vibration/pulsation
- ▶ **Calibrate rear view mirror**  
Calibrate rear view mirror compass to proper zone and check self-dimming function/lighting (if equipped)

### Driver Assistance

- ▶ **Verify operation of parking system (if equipped)**  
Verify operation of Audi parking system sensors with rear view camera (if equipped)
- ▶ **Verify all vehicle Head-up display functionality (if equipped)**  
Verify the image can be adjusted properly in the viewing area of the windshield. Verify NAV directions, speed, cruise control, and lane assist are all visible in Head-Up Display (as equipped)