

Instrument cluster: Always boots in main menu (trip/total mileage) / Last mode inoperative

Topic number	LI54.30-P-064548
Version	1
Design group	54.30 Instrument cluster/display instruments/warning devices
Date	07-20-2016
Validity	Model 117; 156; 166; 172; 231; 242; 246; 292 up to code 807
Reason for change	
Reason for block	

Complaint:

The most recently selected menu setting (e.g. Navigation) is not shown again in the multifunction display of the instrument cluster after bus idle. The main menu (trip/total mileage) is always displayed

Cause:

Communication between engine control unit and instrument cluster.

Remedy:

Immediate measure:

Deactivate the low-voltage recuperation display in the "Trip computer" menu; to do this, the code 910 must be entered in VeDoc and SCN coding of the engine control unit must be performed.

This field organization code deactivate the low-voltage recuperation display. The customer must be informed about this.

Note:

New software for the instrument cluster is planned and is expected to be available with Xentry version 11/16. This software will also restore the function of the low-voltage recuperation display.

We will notify you of the current status in this document.

Symptoms
Communication/information / Information display / Displays / Multifunction display / Function / Nonfunctional
Communication/information / Information display / Displays / Multifunction display / Multifunction display, menu / Faulty display

Operation numbers/damage codes				
Op. no.	Operation text	Time	Damage code	Note

XENTRY TIPS

54-0992	CODE ECU	5 AW	54581 f1	
---------	----------	------	----------	--