

Technical product information

Topic	New Continental GT/GTC And Flying Spur - Brake Pad Wear Indicator
Market area	Bentley: worldwide (2WBE),Hongkong-Macau (5HK)
Brand	Bentley
Transaction No.	2042924/1
Level	EH
Status	Approval
Release date	

New customer code

Object of complaint	Complaint type	Position
Information, navigation, communication, entertainment -> Symbolic information indicators -> Brake pad wear indicator	functionality -> activates	

New workshop code

Object of complaint	Complaint type	Position
Running gear -> Brake system -> Pad wear indicator contact	electrics -> supply cable damaged	> not specified <

Vehicle data

New Continental GT/GTC And Flying Spur

Salestypes

Type	MY	Brand	Designation	Engine code	Gearbox code	Final drive code
393*	2012	E		*	*	*
393*	2013	E		*	*	*
393*	2014	E		*	*	*
393*	2015	E		*	*	*
393*	2016	E		*	*	*
394*	2012	E		*	*	*
394*	2013	E		*	*	*
394*	2014	E		*	*	*
394*	2015	E		*	*	*
394*	2016	E		*	*	*
4W2*	2014	E		*	*	*
4W2*	2015	E		*	*	*
4W2*	2016	E		*	*	*

Documents

Document name
master.xml
master.doc

Customer statement / workshop findings

Brake Pad Wear Indicator warning illuminated on the Drivers Instrument Panel.

Brake Pad Wear Indicator cable is damaged.

Technical background

The rear Brake Pad Wear Indicator cable is not currently available as an individual service item.

The replacement part detailed within this TPI is only applicable to rear brakes.

NOTE: Rear brake pad replacement kits contain two Brake Pad Wear Indicator cables as standard.

Production change

Not Applicable – service item only.

Measure

On complaint of the Brake Pad Wear Indicator illuminating on the Drivers Information Panel, check the thickness of the brake pad linings –

Refer to Gr.46. Check the thickness of the brake pads – Wheels removed.

If the brake pads are in a serviceable condition, inspect the Brake Pad Wear Indicator cables for damage.

Damaged rear Brake Pad Wear Indicator cables should be replaced. Damaged front Brake Pad Wear Indicator cables will require replacement brake pads.

Refer to – Gr.46, Front Brake Pads – To Remove and Refit.

Warranty accounting instructions

Normal warranty policies apply

Warranty Type 110 or 910

Labour Operation Code 46 39 19 99 (for RO open date on or before 11 April 2016)

46 39 56 00 (for RO open date after 11 April 2016)

Damage Service Number 46 39

Damage Code 00 25

Time 60 TU

Parts information

3W0.698.437	Brake Pad Wear Indicator
--------------------	---------------------------------

