Product Knowledge

Cayman (982) **1**

Binder - PPK, Group 16-18

Location of Identification Plate, Chassis/VIN, Paint and Engine Number

Vehicle Data Label

Vehicle identification label is on the inside of the maintenance book. It Contains all important data about your car. This label contains the following information:

- Vehicle Identification Number (VIN)
- Vehicle code
- Engine and transmission code
- Paint Code/Interior Code
- Option codes



Vehicle Identification Number (1)

In accordance with Federal Safety Regulations, the vehicle identification number of your car is located at the bottom left of the windshield frame and can be seen from the outside.

Vehicle Identification Number (2)


The vehicle identification number is also under the front passenger seat.

Transmission Number

Refer to Workshop Manual for location.


Paint Data

The paint data is included on the Vehicle Data Label.




Tire Pressure (3)

Tire pressure label is on the left driver side door lock plate.



Engine Number (4)

The engine number is located on the belt side on the right crankcase half and can be read from below in installed condition.



Safety Compliance Sticker (3)

The safety compliance sticker is your assurance that your new Porsche complies with all applicable Federal Motor Vehicle Safety Standards which were in effect at the time the vehicle was manufactured. This sticker also shows the month and year of production and the vehicle identification number of your car (perforations) as well as the Gross Vehicle Weight Rating and the Gross Axle Weight Rating.

