



GET YOUR PHIL Friday

RV'ing tips n tricks

TIP #27

Heater Won't Ignite ?

My red key disconnect is on, my propane is on, I have power inside the coach and the water heater switch is on, but my water heater will not ignite.

Check:

1) The Reset button on the water heater. You will find this reset inside the water heater vent door on the outside of the vehicle.



2) Check the water pump/water heater fuse in the fuse panel.



3) Check the igniter wire attached to the control box to ensure the spade connection is attached. (The control box will be located inside the vehicle close to the water heater).



4) Check the burner tube for debris.

