

Here is the procedure for updating the becker map pilot.

Content Manager BeckerÆ MAP PILOT

The Content Manager BeckerÆ MAP PILOT is a PC based application containing a number of important functions to help you manage the content on your BeckerÆ MAP PILOT. With the Content Manager BeckerÆ MAP PILOT you can:

- ï back up the content saved on the BeckerÆ MAP PILOT to your PC and restore it later to your BeckerÆ MAP PILOT,
- ï download current content from the Internet and install it on the BeckerÆ MAP PILOT. To use the Content Manager BeckerÆ MAP PILOT, you will need the USB cable provided as well as a computer that meets the following minimum requirements:
- ï Microsoft Windows XP (SP2), Vista or Windows 7 operating system
- ï Microsoft Internet Explorer 7 or higher
- ï PC with USB 2.0
- ï Fast Internet connection with more than 2 Mbit/s
- ï At least 10 GB hard disk space.

Installing the Content Manager BeckerÆ MAP PILOT

You can install the Content Manager BeckerÆ MAP PILOT on your computer with the following steps:

- > Connect the USB interface of the BeckerÆ MAP PILOT directly to the USB port of the computer using the USB cable provided. After a short time, the BeckerÆ MAP PILOT is displayed as a removable storage medium on the computer. Installation should start automatically.
- > Follow the instructions of the software. The Content Manager BeckerÆ MAP PILOT can be started immediately after installation. This completes the installation procedure.

Starting the Content Manager

- > Connect the USB interface of the BeckerÆ MAP PILOT directly to the USB port of the computer using the USB cable provided. After a short time, the BeckerÆ MAP PILOT is displayed as a removable storage medium on the computer.
- > Click on Start
- > All Programs on the computer.
- > Select Content Manager
- > Click on Content Manager.

The Content Manager BeckerÆ MAP PILOT is started.