


| | |
|--|--------------------------------|
| Subject: DO NOT PERFORM OPERATIONAL TESTING OF THE SMART CITY BRAKE SUPPORT (SCBS) SYSTEM | M-Tips No.: MT-016/17 |
| | Last Issued: 10/18/2017 |

DESCRIPTION

The Smart City Brake Support (SCBS) system alerts the driver of a possible collision using an indication in the display and a warning sound when the Forward Sensing Camera (FSC) detects a vehicle ahead and determines that a collision with a vehicle ahead is imminent. In addition, the system reduces damage in the event of a collision by operating the brake control when the system determines that a collision is unavoidable. It may also be possible to avoid a collision depending on the relative speed between your vehicle and the vehicle in front of you. In addition, when the driver depresses the brake pedal, the brakes are applied firmly and quickly to assist.



Under the following conditions, the Smart City Brake Support (SCBS) system may not operate normally:

- The Smart City Brake Support (SCBS) system will not operate if the driver is performing driving operations (accelerator pedal and steering wheel).
 - The accelerator or brake pedal is depressed.
 - The steering wheel or selector lever is being operated.
- If there is the possibility of partial contact with a vehicle ahead.
- The vehicle is driven on a slippery road surface such as wet roads or icy or snow-bound roads.
- The braking performance is adversely affected due to cold temperatures or wet brakes.
- The vehicle is driven at the same speed as the vehicle ahead.



DO NOT PERFORM OPERATIONAL TESTING OF THE SMART CITY BRAKE SUPPORT (SCBS) SYSTEM

If the warning indicator light is not illuminated and there are no codes stored in the system, the system is operating properly, and Mazda cannot perform any additional testing of the system. Dealers and customers should never attempt to test or recreate crash scenarios under any circumstances because that could lead to an accident and injuries.

Please refer customers to their vehicles owner's manual section 4 (When driving) for more information on the operation of the SCBS system.