

	GROUP Body	MODEL 2018MY Stinger (CK)
	NUMBER PS536	DATE December 2017
 		
SUBJECT: ACCESSING DRIVER DOOR LOCK CYLINDER		

This pitstop provides information on the location and procedure to operate the driver's door lock cylinder on all 2018MY Stinger (CK) vehicles.

To access the driver's door lock cylinder:

1. Remove the mechanical key (A) from the fob.
2. Locate the trim cover release catch (B) on the underside of the door handle.
3. Depress the release catch (B) upward using the mechanical key (A) and carefully pull the trim cover (C) upward and away from the door handle to expose the door lock cylinder (D).
4. Insert mechanical key (A) into the door lock cylinder (D).
5. Turn the key clockwise to lock, and turn the key counterclockwise to unlock the driver's door.
6. Carefully snap the door lock cylinder trim cover (C) back on door handle downwards after use.

