

H[®] PRODUCT UPDATE


VANTRAAX[®] Decals

LIT NO: P36026


DATE: December 2017

Hendrickson Trailer Commercial Vehicle Systems announces a change to VANTRAAX[®] slider suspension system decals. In the past, L1032 Inspection & Safety Decal and L1033 QUIK-DRAW[®] Decal were shipped with VANTRAAX slider suspension systems.

Beginning early January 2018, L1032 Inspection & Safety Decal will no longer be included in VANTRAAX system shipments. VANTRAAX shipments will now only include L1033 QUIK-DRAW Decal, which has been updated to include the information from L1032 Inspection & Safety Decal.

 L1032 01-08 ECN 16203 ©2008 Hendrickson USA, L.L.C. (U.S. Rights) Hendrickson International Corporation (Rights Outside U.S.) All Rights Reserved www.hendrickson-intl.com 866-RIDEAIR (743-3247) INTRAAX[®] / VANTRAAX[®] SUSPENSION INSPECTIONS Inspect the following items during regular vehicle maintenance: - Vehicle frame, suspension beams, brackets and other structural components for cracks or other damage - All fasteners for proper torque or damage - All welds for cracks or other damage - Air springs for chafing, rubbing, or damage - Shock absorbers for leaks or damage - Suspension ride height 	⚠ WARNING DO NOT operate vehicle without all slider pins completely through body rail holes. Unsecured slider box can cause loss of vehicle control and result in death, severe personal injury or property damage. Engage all four slider pins completely through body rail holes. INTRAAX / VANTRAAX SUSPENSION SAFETY ⚠ CAUTION IMPROPER AIR SPRING PRESSURE CAN CAUSE VEHICLE OR SUSPENSION DAMAGE OR SEVERE PERSONAL INJURY. DO NOT OPERATE THE VEHICLE WITHOUT AIR PRESSURE IN THE AIR SPRINGS. Lower the trailer onto the internal air spring bumpers if it is supported by the landing gear and parked with a payload for any length of time. Lower the trailer onto the internal air spring bumpers for safe loading / unloading.	⚠ AVERTISSEMENT NE PAS utiliser le véhicule si toutes les broches de blocage ne sont pas entièrement enfoncées dans les ouvertures des longerons. Une boîte coulissante mal fixée peut entraîner la perte de contrôle du véhicule et causer la mort, de graves blessures ou des dommages matériels. Engager entièrement les quatre broches du système coulissant dans les ouvertures des longerons. SÉCURITÉ DES SUSPENSIONS INTRAAX / VANTRAAX ⚠ ATTENTION UNE MAUVAISE PRESSION DANS LES RESSORTS PNEUMATIQUES PEUT ENDOMMAGER LE VÉHICULE OU LA SUSPENSION OU PROVOQUER DES BLESSURES CORPORELLES. NE PAS UTILISER LE VÉHICULE SANS PRESSION DANS LES RESSORTS PNEUMATIQUES. Baisser la remorque sur les bultoirs internes des ressorts pneumatiques si elle est stationnée chargée et reste posée sur sa béquille pendant un certain temps. Baisser la remorque sur les bultoirs internes des ressorts pneumatiques pour charger et décharger en toute sécurité.
--	--	--

L1032 Inspection & Safety Decal

⚠ WARNING DO NOT operate the vehicle without all slider pins completely through body rails. ⚠ CAUTION DO NOT operate the vehicle without air pressure in air springs QUIK-DRAW[®] OPERATING INSTRUCTIONS TO REPOSITION THE SLIDER: - On a level surface, apply trailer parking brakes. - Remove manual stop bar (if applicable) and move it to desired position. - Pull QUIK-DRAW valve knob out to retract locking pins (never force or use tools on knob). - Gently rock trailer fore and aft to fully retract any bound pins. - Move trailer until slider is in desired position. Trailer parking brakes must remain applied. - Push QUIK-DRAW valve knob in to engage locking pins. - Visually check all locking pins for proper engagement — chamfered ends of locking pins must project through body rail at all four locations. - Install manual stop bar directly behind slider system. - Gently rock trailer fore and aft to check pin engagement. For more information, refer to Hendrickson literature number L738 QUIK-DRAW[®] Operating and Maintenance Procedures.  Trailer Commercial Vehicle Systems www.hendrickson-intl.com 866-RIDEAIR (743-3247) L1033 Rev A 05-17 ECN 30008	 Pins released goupilles désengagées Pins engaged goupilles engagées Warranty and important literature: Garantie et autres publications importantes : L583 Comprehensive Warranty Statement L583FR Énoncé intégral de la garantie L1074 Slider Suspension Information www.Hendrickson-intl.com/TrailerLit 	⚠ AVERTISSEMENT NE JAMAIS opérer le véhicule sans avoir toutes les goupilles engagées correctement. ⚠ ATTENTION NE PAS opérer le véhicule sans air dans les ressorts pneumatiques. MODE D'EMPLOI QUIK-DRAW[®] Pour déplacer la glissière : - Sur une surface plane, appliquer le frein de stationnement de la remorque. - Enlever la barre d'arrêt (si présente) et la replacer à la position désirée. - Tirer le bouton QUIK-DRAW pour rétracter les goupilles. (ne jamais forcer ou utiliser des outils sur le bouton). - Déplacer lentement la remorque d'avant à arrière pour s'assurer que toutes les goupilles soient rétractées. - Déplacer la remorque jusqu'à ce que la glissière soit à la position désirée. Les freins de la remorque doivent rester engagés. - Pousser le bouton QUIK-DRAW pour réengager les goupilles. - Vérifier visuellement que les goupilles soient engagées correctement — les extrémités chamfrainées doivent traverser les rails aux quatre emplacements. - Repositionner la barre d'arrêt derrière la glissière. - Déplacer lentement la remorque d'avant à arrière pour s'assurer que toutes les goupilles soient bien engagées. Pour de plus amples informations, vous référer à la publication L738 QUIK-DRAW[®] Operating and Maintenance Procedures. ©2017 Hendrickson USA, L.L.C. All Rights Reserved Printed in USA
---	--	---

L1033 QUIK-DRAW[®] Decal

As always, Hendrickson is committed to providing world-class, quality suspension products and exceptional customer service. For additional information, please contact us at 1-866-RIDEAIR (743-3247).

Call Hendrickson at **330.489.0045** or **866.RIDEAIR (743.3247)** for additional information.



www.hendrickson-intl.com

TRAILER COMMERCIAL VEHICLE SYSTEMS
2070 Industrial Place SE
Canton, OH 44707-2641 USA
866.RIDEAIR (743.3247)
330.489.0045 • Fax 800.696.4416

Hendrickson Canada
250 Chrysler Drive, Unit #3
Brampton, ON Canada L6S 6B6
800.668.5360
905.789.1030 • Fax 905.789.1033

Hendrickson Mexicana
Circuito El Marqués Sur #29
Parque Industrial El Marqués
Pob. El Colorado, Municipio El Marqués,
Querétaro, México C.P. 76246
+52 (442) 296.3600 • Fax +52 (442) 296.3601