



Countries: CANADA, UNITED STATES **Document ID:** IK1300161
Availability: ISIS, NotSIR **Revision:** 0
Major System: TRANSMISSION **Created:** 10/23/2017
Current Language: English **Last Modified:** 10/23/2017
Other Languages: NONE **Author:** William Katschke
Viewed: 73

[Less Info](#)

Hide Details

Coding Information

Copy Link 	Copy Relative Link 	Bookmark View My Bookmarks	Add to Favorites 	Print 	Provide Feedback 	Helpful 1	Not Helpful 0
----------------------	-------------------------------	--	-----------------------------	------------------	-----------------------------	-------------------------	-----------------------------

Title: Transmission Shift Lever Contacting The Dashboard**Applies To:** HX with Eaton Transmissions

CHANGE LOG

Please refer to the change log text box below for recent changes to this article:

10/23/2017 - Initial Article Release

DESCRIPTION

This document will provide replacement part information if the shift lever is coming in contact with the dashboard in HX model trucks.

SYMPTOM(s)

Transmission shift lever comes in contact with the dashboard, see figures 1 & 2 below.

Diagnostic Trouble Code(s) & Dashboard Indicator Light(s):
Not Applicable

DTC/Light	Description
N/A	N/A

Customer Observations or Concerns:

Shift lever coming in contact with the dashboard.

SPECIAL TOOL(s) / SOFTWARE

Tool Description	Tool Number	Comments	Instructions
N/A	N/A	N/A	N/A

SERVICE PARTS INFORMATION

Kit Description	Part Number	Quantity Required
LEVER, TRANSMISSION, SHIFT ASS	4092022C91	1

DIAGNOSTIC STEP(s)

 **WARNING:**

To prevent property damage, personal injury, and / or death, park vehicle on a hard, flat surface, turn the engine off, set the parking brake, and install wheel chocks to prevent the vehicle from moving in either direction.

 **WARNING:**

To prevent property damage, personal injury, and / or death, if the vehicle must be raised, do not work under the vehicle supported only by jacks. Jacks can slip or fall over.

 **WARNING:**

To prevent personal injury and / or death, always wear safe eye protection when performing vehicle maintenance.

 **WARNING:**

To prevent property damage, personal injury, and / or death, keep flames or sparks away from vehicle and do not smoke while servicing the vehicle's batteries. Batteries expel explosive gases.

 **WARNING:**

To prevent property damage, personal injury, and / or death, remove the ground cable from the negative terminal of the battery box before disconnecting any electrical components. Always connect the ground cable last.

1. Bring vehicle into shop and park on a flat surface
2. Shift transmission into park or neutral, set parking brake, and install wheel chocks
3. If shift lever is contacting the dashboard (as shown in Figures 1 & 2) replace shift lever with the part number listed in Service Parts Information.

Figure 1:





Figure 2:



REPAIR STEP(s)

1. Refer to Fuller® Heavy-Duty Transmissions [TRSM0670 EN-US](#) for shift lever replacement instructions.

2. Remove wheel chocks

WARRANTY INFORMATION

Warranty Claim Coding:

Refer to the [Warranty Coding Manual](#) for Group and Noun Codes.

Standard Repair Time(s):

Refer to the [SRT Manual](#) for Repair Times

OTHER RESOURCES

[Master Service Information Site](#)



Hide Details

Feedback Information

Viewed: 72

Helpful: 1

Not Helpful: 0

No Feedback Found

Copyright © 2017 Navistar, Inc.