



Countries:
Availability: ISIS, FleetISIS, IsSIR
Major System: CAB / SLEEPER / HOOD
Current Language: English
Other Languages: NONE
Viewed: 81

Document ID: IK1600232
Revision: 1
Created: 9/6/2017
Last Modified: 10/11/2017
Author: Allan Hertko

[Less Info](#)
[Hide Details](#)

Coding Information

Copy Link 	Copy Relative Link 	Bookmark View My Bookmarks	Add to Favorites 	Print 	Provide Feedback 	Helpful 0	Not Helpful 0
----------------------	-------------------------------	--	-----------------------------	------------------	-----------------------------	-------------------------	-----------------------------

Title: LT Air Deflector / Fairing Vibration at Highway Speeds

Applies To: LT

Change Log

Please refer to the change log text box below for recent changes to this article:

10/11/2017 - Specified sealant product
 10/10/2017 - Initial Article Release

Description

Some LT vehicles equipped with a sleeper air deflector combination may exhibit a cab vibration, rumble or drone while cruising at highway speeds (40-70 mph).

Symptom(s)

Vibration / Drone / Rumble / Gap

Parts

Part Number	Description	Quantity	Comment
2611726C1	Bostik® SuperTrans adhesive	1	10.3 oz cartridge

Diagnostic and Repair Steps

Step 1: Inspect the air fairing for excessive gaps prior to road-test. See following four images for examples.

Air fairing is flush no gaps are present



Air fairing has a gap towards the center



Step 2: Road-test the vehicle with a co-worker to pinpoint the concern.

Step 3: Use soap and water to clean the affected area and air dry.

Step 4: Apply a thin layer of Bostik® SuperTrans to seal the gaps.

Water drainage is necessary around the air fairing. Do NOT make a complete seal around the air fairing.

Repairs have been made sealing the gap



Step 5: Depending on ambient temperature let adhesive dry for approximately one hour before road-testing.

Step 6: Verify repair.

WARRANTY INFORMATION

Warranty Claim Coding:

Refer to the [Warranty Coding Manual](#) for Group and Noun Codes.

Standard Repair Time(s):

Refer to the [SRT Manual](#) for Repair Times

OTHER RESOURCES

[Master Service Information Site](#)

 Hide Details

Feedback Information

Viewed: 80

Helpful: 0

Not Helpful: 0

No Feedback Found