

Tech Tip L-TT-0220-17

February 28, 2017

Reverse Linked Mirror - Mirror Angle Customization in Owner's Manual

USA

Service Category
Vehicle Exterior

Mirror (ext)

2015-2017 GX460

APPLICABLE VEHICLES

2015-2017 GX460

CONDITION

Some 2015-2017MY GX460 owners may have a concern with the inability to customize their outer mirrors when shifting the vehicle to Reverse ("R" position) as described in the Owner's Manual. An excerpt of the manual is shown below.

Linked mirror function when reversing (if equipped)

When the mirror select switch is in the L or R position, the outside rear view mirrors will automatically angle downwards when the vehicle is reversing in order to give a better view of the ground.

To disable this function, move the mirror select switch to the neutral position (between L and R).

Adjusting the mirror angle when the vehicle is reversing

With the shift lever in R, adjust the mirror angle at a desired position. The adjusted angle will be memorized and the mirror will automatically tilt to the memorized angle whenever the shift lever is shifted to R from next time.

The memorized downward tilt position of the mirror is linked to the normal position (angle adjusted with the shift lever in other than R). Therefore, if the normal position is changed after adjustment, the tilt position will also change.

When the normal position is changed, readjust the angle in reversing.

RECOMMENDATIONS

On 2015-2017 GX460 models equipped with this feature, the side mirrors cannot be customized to a specific memorized angle when the shift lever is in the "R" position. The text highlighted above is incorrect for this model.

LINK REFERENCES

This Tech Tip does not contain any link references

Expires on

02/28/2018

© 2017, Lexus, a Division of Toyota Motor Sales, USA

Page 1 of 1