

# Initialization of Parking Assist Monitor System

**Service Category** General

**Section** Pre-Delivery Service

**Market** USA

Lexus Supports  
ASE Certification 

## Applicability

| YEAR(S) | MODEL(S)      | ADDITIONAL INFORMATION |
|---------|---------------|------------------------|
| 2018    | LC500, LC500H |                        |

### REVISION NOTICE

April 6, 2017 Rev1:

- The title, Introduction, and Initialization Procedure sections have been updated.
- Any previous printed versions of this bulletin should be discarded.

## Introduction

The Parking Assist Monitor System aids the driver by displaying an image of the area behind the vehicle while in reverse.

When the DCC Fuses are removed or the battery terminal is disconnected, the power source to the steering angle sensor is cut OFF. When the DCC Fuses are reinstalled or the battery terminal is reconnected, the rear view monitor will operate, but the steering angle sensor center position MUST be set through system initialization before park assist will become operational.

Initialize the Parking Assist Monitor System AFTER installing the DCC Fuses during Pre-Delivery Service (PDS).

### NOTE

**ANYTIME the battery terminal has been disconnected, the Parking Assist Monitor System MUST be initialized.**

## Warranty Information

| OP CODE | DESCRIPTION                | TIME | OFF | T1 | T2 |
|---------|----------------------------|------|-----|----|----|
| N/A     | Not Applicable to Warranty | —    | —   | —  | —  |

## Initialization of Parking Assist Monitor System

---

### Initialization Procedure

1. Start the engine (Hybrid System "READY").
2. Apply the parking brake.
3. Check if the Parking Assist Monitor System is operative by moving the shift lever to the "R" position. Check to see if the "Estimated course line" is shown.

**NOTE**

If the "Estimated course line" is shown, then initialization is complete.

4. Move the shift lever to the "P" position and turn the steering wheel lock to lock.
5. Move the shift lever to the "R" position.

When "Estimated course line" appears on the rear view monitor as shown, the initialization of the Parking Assist Monitor System has completed.

**Figure 1. Guide Line Display**

