

Front Wheel Opening Extension Pad Installation During PDS

Service Category General

Section Pre-Delivery Service

Market USA



Applicability

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION
2018	RC F, RC300, RC350	

Introduction

The front wheel opening extension pad set (right and left front wheel opening extension pads and six self-tapping screws) is loaded in the luggage compartment at the assembly plant to avoid damage in transit. Install the front wheel opening extension pads onto the vehicle during Pre-Delivery Service (PDS).


Warranty Information

OP CODE	DESCRIPTION	TIME	OFF	T1	T2
N/A	Not Applicable to Warranty	-	-	-	-

Installation Procedure

Install the right and left front wheel opening extension pads with the six self-tapping screws.

Figure 1.



1	Self-tapping Screw
----------	---------------------------