Preliminary Information

PIC6324 Left Side Blind Zone Indicator Comes on Randomly While Driving with No Objects Present

Proactive

Models

| Brand: | Model: | Model Years: | VIN: | | Engine: | Transmissions: |
|--------|--------|--------------|------|-----|-----------|----------------|
| | | | from | to | Eligilie. | Hansinissions. |
| Buick | Encore | 2018 | All | AII | All | AII |

| Involved Region or Country | North America | | | | |
|----------------------------|--|--|--|--|--|
| Additional Options (RPO) | UFT | | | | |
| Condition | A customer may notice that the left side blind zone indicator comes on randomly while driving without any objects present. It is possible that the indicator may stay on for an extended amount of time. | | | | |
| Cause | Engineering is investigating this concern | | | | |

Correction:

Engineering is aware and currently working on this issue. The PI will be updated when a repair is available.

Version History

| Version | 1 |
|----------|----------------------|
| Modified | Created on 2/12/2018 |

















