

Pleasure-Way

Firestone 2 CORNER WIRELESS AIR COMMAND



1. Turn on the 12 volt disconnect switch for the coach located in the cabinet under the furnace.

2. Press any button on the air bag remote control gauge to turn it on. Once it has been turned on it will automatically display how much air pressure is currently in the air bags.

MODE and ARROW

Keys are used to cycle through the screen and make selections to inflate/deflate the air springs. Pressing the **MODE** button once will display an arrow. You want this to point to the (LR) then the (RR) the front corners are not part of this system. Pressing the up/down button at this time will change the pressure in the air spring. Continuing to press the **MODE** button will cycle through the corners:

IMPORTANT BOTH AIR BAGS SHOULD BE SET BETWEEN 55 & 60 POUNDS.



****Not all functions are used in the 2 Corner System****

- 1 Front Left (LF) ****Skip this corner****
- 2 Front Right (RF) ****Skip this corner****
- 3 Rear Left (LR)
- 4 Rear Right (RR)
- 5 Fronts (LF & RF) ****Skip this step****
- 6 Rears (LR & RR) ****Skip this step****
- 7 All corners (LF,RF,LR,RR) ****Skip this step****
- 8 Returns to single selection, Set (LR) then (RR)

Once the pressure has been selected, the system will turn on the compressor or open the exhaust valve to change the pressure. The change can be stopped by pressing either arrow key. The display will turn off after 20 seconds of inactivity. To show the display, just press any of the buttons. The compressor will automatically maintain the set pressures. It is normal for the air bags to lose some pressure over time. As long as the 12 volt disconnect switch is turned on the compressor will automatically engage and pump the air bags up to the set pressure.