

Table 1 provides gauge part numbers for Cargo vehicles.

Gauge Description	Part Number	Remarks	Module
Voltmeter	F3HZ-10797-AA		836
Air Pressure	F3HZ-2557-AA	Buzzer D0HZ-2573-A	840
Fuel Level	F3HZ-9280-AA	Sending Unit RGI/8340-00284, 22-in-Deep Tank Sending Unit A22-42390-004, Short Tank Sending Unit A22-42390-003, Long Tank Fuel Tank Gasket 22-27156-00	844
Engine Oil Pressure	F3HZ-9273-AA	Oil Pressure Sending Unit E9HZ-9278-B	852
Engine Water Temperature	F6HZ-10883-CA	Sending Unit MBT/A6805420017	856
Transmission Oil Temperature	F6HZ-10883-BB	Sender AMA/163075, Allison Transmission	864
Speedometer	F6HZ-17255-LA F6HZ-17255-MA	mph, with Tripometer kph, with Tripometer (See Module 810 or 817 for Sending Unit)	810
Tachometer	F6HZ-17360-GA 22-48428-000	3,500 rpm, without Hour Meter 3,500 rpm, with Hour Meter (See Module 819 for Sending Unit)	812

Table 1, Cargo Gauges