

SS - 1033273: WST 5700XE Sun Visor Cracks - Mounting Screws Loose

WST 5700 Sun Visor Cracks - Mounting Screws Loose

Applicable Vehicles

WST 5700XE

Symptoms

Sun Visors cracking and Sun Visor mounting screws loose.

Issue


Reports of sun visors cracking and/or mounting screws loose have been received from some areas with windy conditions.

Solution

When replacing the Sun Visors, installing/torqueing the mounting screws (or removing and retorquing loose mounting screws) it is recommended to use Loctite 272:



When replacing Sun Visor or re-torquing loose screws, use Loctite 272 thread locker when installing and torquing mounting screws.



SS - 1033273: WST 5700XE Sun Visor Cracks - Mounting Screws Loose

This is an informative bulletin only.

Contact your WST DSM or WST Field Service Support if you have comments or questions.