## 23Y9 Campaign Tip



## **Differential/Exhaust Pressure Sensors**

This notice is for:	<ul><li>✓ Dealer Principal</li><li>✓ Sales Manager</li></ul>	<ul><li>✓ Service Manager</li><li>✓ Parts Manager</li></ul>	<ul><li>✓ Warranty Administrator</li><li>✓ Technicians</li></ul>
Date	May 23, 2018		
Issue	Differential/Exhaust Pressure Sensors cracking due to improper removal or storage.		
Resolution	The bolts for the Differential and Exhaust Pressure Sensors and mounting bracket fastener/s must be removed before removing or disturbing the pressure sensor pipes secured on the timing cover.		
	The labor operations contained in the 23Y9 Campaign Circular <b>MUST be followed IN THE ORDER WRITTEN</b> during removal/reinstallation of the Exhaust Pressure Sensors. The sensors <u>ARE FRAGILE</u> and can be damaged if:		
	Order of operations in the 23Y9 are not followed.		
	Excessive or unnecessary force is used.		
	Sensors are not stored or handled with care.		