

CabinWatch® Fails After About 10 Minutes of Continuous Use

AFFECTED VEHICLES

Year	Model	Trim
2018	Odyssey	EX-L and above

We're getting reports that after about **10 minutes** of continuous CabinWatch use, the Display Audio screen shows an error message and goes black or stops working. We're aware of this issue and have it under investigation. This issue affects just CabinWatch and goes away after cycling the ignition.

For now, if you run into this, don't replace any parts. We'll let you know when there's a solution available.