

DD13, DD15, DD16 Check Engine Light...



Nahum Veach 6 posts since Jan 30, 2015

DD13, DD15, DD16 Check Engine Light (CEL) Flashing or Blinking Sep 9, 2016 2:39 PM

I have had a couple of dealers get stumped by the Check Engine Light Flashing on Detroit engines, yet no codes are logged. The most likely cause is the result of the PasSmart feature being enabled and the allocated "go faster" minutes are ready to expire.

From the A&I Manual:

"When the Passing Speed Duration time expires, the AWL will begin to flash one minute prior to ramping the VSL back down

to the normal VSL (Max Road Speed). The rampdown event always takes 5 seconds regardless of the Passing Speed

Increment programmed into the controller. The ramp down alert can be distinguished from an engine fault warning in that the

AWL flashes for the PasSmart alert and remains on constantly for an engine fault."

Make it a great day!