

## Message (yellow) in IC "Active Brake Assist functional scope currently restricted, see Owner's Manual"

---

Topic number	LI54.70-P-068094
Version	2
Function group	54.70 Proximity warning system
Date	07-09-2018
Validity	BR177
Reason for change	Added damage code
Reason for block	

---

### Complaint:

Active Brake Assist functional scope currently restricted

-> see owner's manual.

### Note:

The ABA control unit (A108 - Active Brake Assist (ABA)) contains the following DTC

- C163691

### Cause:

Transport mode or production mode is active.

### Remedy:

Deactivate transport mode and drive for approx 1 km with the vehicle.

The DTC then switches to passive and the sensor can be calibrated.

<b>Symptoms</b>
Communication/information / Information display / Displays / Multifunction display / Multifunction display, error messages / Pre-Safe Inoperative
Communication/information / Assistance and warning systems / Brake Assist / Warning message in instrument cluster
Communication/information / Assistance and warning systems / Brake Assist / Malfunction

<b>Control unit/fault code</b>		
Control unit	Fault code	Fault text
A108 - Active Brake Assist (ABA) (FCW177)	C163691	The calibration of the control unit 'DISTRONIC' has a malfunction. The parameter is outside the permissible range.

# XENTRY TIPS

---

Operation numbers/damage codes				
Op. no.	Operation text	Time	Damage code	Note
			54W10 G1	Radar sensor, right, inner, bumper, front