



Countries: AUSTRALIA, BAHAMAS, BOLIVIA, BRAZIL, BELIZE, CANADA, CHILE, TAIWAN, COLOMBIA, COSTA RICA, DOMINICAN REPUBLIC, ECUADOR, EL SALVADOR, TRINIDAD AND TOBAGO, UNITED STATES, URUGUAY, VENEZUELA, MEXICO, ARUBA, NICARAGUA, PERU, PUERTO RICO, Curaçao, GUAM, GUATEMALA, GUYANA, HAITI, HONDURAS, JAMAICA, KOREA, SOUTH KOREA, PANAMA, SOUTH AFRICA

Document ID: IK0800038

Availability: ISIS, Bus ISIS, FleetISIS, IsSIR

Major System: ELECTRICAL SYSTEM

Current Language: English

Other Languages: [Français](#), [Español](#)

Viewed: 3506

Revision: 6

Created: 1/4/2007

Last Modified: 12/5/2018

Author: Jonathan Delmore

[Less Info](#)

Hide Details

Coding Information

Copy Link 	Copy Relative Link 	Bookmark View My Bookmarks	Add to Favorites 	Print 	Provide Feedback 	Helpful 631	Not Helpful 556
----------------------	-------------------------------	--	-----------------------------	------------------	-----------------------------	---------------------------	-------------------------------

Title: Park Lights Come Whenever the Key is On / Headlight Switch Part Numbers For Pre-2007 NGV

Applies To: All Pre- 2007 NGV

CHANGE LOG

Please refer to the change log text box below for recent changes to this article:

12/5/2018 - Changed part numbers for headlight switches.
09/28/2016 - Re-published article for valid information.

DESCRIPTION

Version 9 cluster, must replace it with a version 9 cluster and a version 10 or newer cluster, must replace it with a version 10 or newer cluster. They are **not** interchangeable. If the parking lights come on anytime the key is on, the issue may be mixed version 10 or newer cluster with a version 9 headlight switch or vice versa. The headlight switches are **not** interchangeable either.

Parts Information

Version 10.0 or Newer

Instrument clusters (Includes Standard Gauges)	3576990C91 English/English 3576991C91 Metric/Metric 3576992C91 English/Metric
Compatible Headlight Switch Assemblies	2509620C91 Two Switch 2509620C92 Three Switch Circuit Board ID 25-272808000A*

Compatible Warning Speaker	2509518C91
<p>*Headlight Switch Assemblies do not have part number identification on the housing. In order to identify the generation of Headlight Switch Assembly, remove the Work Light Switch, or in its absence the blank filler in the far right position, and read the circuit board number from the edge of the circuit board at the bottom of that cavity.</p>	

Pre-Version 10.0

Instrument Clusters (without Standard Gauges)	3554439C91,2,3 All English 3554440C91,2,3 All Metric
Compatible Headlight Switch Assemblies	2512518C91 Two Switch 2512518C91 Three Switch Circuit Board ID 25-271981-E*
Compatible Warning Speaker	2506754C91
<p>*Headlight Switch Assemblies do not have part number identification on the housing. In order to identify the generation of Headlight Switch Assembly, remove the Work Light Switch, or in its absence the blank filler in the far right position, and read the circuit board number from the edge of the circuit board at the bottom of that cavity.</p>	

 Hide Details

Feedback Information

Viewed: 3505
 Helpful: 631
 Not Helpful: 556

No Feedback Found