



BAHAMAS, BOLIVIA, BELIZE, CANADA, CHILE, TAIWAN, COLOMBIA, COSTA RICA, DOMINICAN REPUBLIC, ECUADOR, EL SALVADOR, TRINIDAD AND TOBAGO, UNITED STATES, URUGUAY, VENEZUELA, ARUBA, NICARAGUA, PERU, PUERTO RICO, Curaçao, GUAM, GUATEMALA, GUYANA, HAITI, HONDURAS, JAMAICA, KOREA, SOUTH KOREA, PANAMA

Countries: BAHAMAS, BOLIVIA, BELIZE, CANADA, CHILE, TAIWAN, COLOMBIA, COSTA RICA, DOMINICAN REPUBLIC, ECUADOR, EL SALVADOR, TRINIDAD AND TOBAGO, UNITED STATES, URUGUAY, VENEZUELA, ARUBA, NICARAGUA, PERU, PUERTO RICO, Curaçao, GUAM, GUATEMALA, GUYANA, HAITI, HONDURAS, JAMAICA, KOREA, SOUTH KOREA, PANAMA

Availability: ISIS, FleetISIS, IsSIR

Major System: ELECTRICAL SYSTEM

Current Language: English

Other Languages: [Français](#), [Español](#),

Viewed: 2106

Document ID: IK0800089

Revision: 5

Created: 3/21/2007

Last Modified: 12/6/2018

Author: Brad Lamparski

[Less Info](#)☒ Hide Details

Coding Information

Copy Link	Copy Relative Link	Bookmark	Add to Favorites	Print	Provide Feedback	Helpful	Not Helpful
		 View My Bookmarks				 202	 240

Title: CF Cluster Odometer Wrong (How to Program Mileage)

Applies To: All CF


CHANGE LOG

Please refer to the change log text box below for recent changes to this article:

12/06/2018 - Added Change Log. Added updated step-by-step image.

DESCRIPTION

When changing a CF cluster, it is necessary to program the mileage into the new cluster with **DLB**, even though the CF doesn't have an ESC.



Hide Details

Feedback Information

Viewed: 2105

Helpful: 202

Not Helpful: 240

No Feedback Found