



Countries: AUSTRALIA, BAHAMAS, BOLIVIA, BRAZIL, BELIZE, CANADA, CHILE, TAIWAN, COLOMBIA, COSTA RICA, DOMINICAN REPUBLIC, ECUADOR, EL SALVADOR, TRINIDAD AND TOBAGO, UNITED STATES, URUGUAY, VENEZUELA, MEXICO, ARUBA, NICARAGUA, PERU, PUERTO RICO, Curaçao, GUAM, GUATEMALA, GUYANA, HAITI, HONDURAS, JAMAICA, KOREA, SOUTH KOREA, PANAMA, SOUTH AFRICA

Document ID: IK0400063

Availability: ISIS, FleetISIS, NotSIR

Major System: BRAKES

Current Language: English

Other Languages: [Portuguese](#)

Viewed: 4055

Revision: 8

Created: 8/21/2009

Last Modified: 10/22/2018

Author: William Knoth

[Less Info](#)

Hide Details

Coding Information

Copy Link	Copy Relative Link	Bookmark	Add to Favorites	Print	Provide Feedback	Helpful	Not Helpful
		 View My Bookmarks				 1318	 448

Title: Brake pedal not returning and sticking slightly in the applied position

Applies To: All Models

CHANGE LOG

Please refer to the change log text box below for recent changes to this article:

10/22/2018 - Updated troubleshooting steps
07/26/2018 - Released article for all models

DESCRIPTION

Brake lights staying on due to brake pedal not returning and binding.

SYMPTOMS

- Cruise control not working
- Brake lights staying on

PARTS INFORMATION

- M8 flat hardened flat washer (8.8 x 17 x 1.6mm) part number 934675R1.

TROUBLESHOOTING

Step	Action	Decision
1	DIAGNOSTIC: Are the brake lights applied with the pedal not being depressed?	Yes: Lift the brake pedal with your hand and release the pedal. If the brake lights turn off the proceed to the resolution. If lights are still on, proceed to other switch, wiring and air system diagnostics.
		No: Lightly press the brake pedal and release. If the lights stay on move to the resolution section. If the lights turn off then no correction is needed.

RESOLUTION

Please click on the link below for detailed instructions for completing this repair

[Pedal Repair Instructions](#) - PDF Document

WARRANTY INFORMATION

Warranty Claim Coding:

Refer to the [Warranty Coding Manual](#) for Group and Noun Codes.

Standard Repair Time(s):

Refer to the [SRT Manual](#) for Repair Times

Hide Details	Feedback Information
	Viewed: 4054 Helpful: 1318 Not Helpful: 448
No Feedback Found	