

## Discharged 12-Volt Battery

### AFFECTED VEHICLES

Year	Model	Trim
2017	NSX	ALL

Does your vehicle not start due to a discharged battery? In some cases, the audio unit is the culprit.

The audio unit might not shut down after the vehicle is turned to OFF, which will cause the audio unit to slowly drain the battery.

If the vehicle applies, you need to follow the procedure in S/B 17-035, *Audio Unit May Display "USB Not Responding."* and update the audio unit.

#### NOTE

Only apply S/B 17-035 if the VIN is listed in the VIN range and the repair procedure has not been applied. If that bulletin doesn't apply, continue with normal system troubleshooting.