



Service Bulletin

34-077

Section

34-Lighting and Wiring

Description

Proper Closure of Power Distribution Box Cover

Release Date

4/8/2019

Introduction

To prevent corrosion of the Power Distribution Box, the cover latches need to be fully engaged.

Resolution

Informational Only

The purpose of this bulletin is to highlight how to identify when the PD box door is properly closed. See the procedure below.

Procedure

The PD box door does not always latch if it is only pressed. Loud, audible clicks can be heard when each latch fully engages.

1. Close the PD box door.
2. Press the door closed.
3. Confirm that both latches are seated. If the latches are not seated, gently, but firmly press the door near the unseated latch.

Figure 1 PD box door latches not seated



Figure 2 PD box door latches properly seated



Authored by: PR

Access to PACCAR's Enterprise Portal is provided as a benefit of doing business with PACCAR. All applications and content accessed through this system are confidential and proprietary and the property of PACCAR Inc and its suppliers, and must be kept strictly confidential pursuant to the contract licensing such access. Disclosure, publication, release or distribution of any material found on PACCAR systems to any person other than employees with a need to know such information is strictly prohibited. All activity on this system is monitored. If PACCAR suspects or discovers any unauthorized activity, access may be immediately terminated without prior notification. Violators may be subject to legal action.

© Copyright 2019 PACCAR Inc. All rights reserved. We welcome your [feedback](#) on this page. For technical questions or concerns about this page, please contact the [DealerNet Webmaster](#).