
18SP735 – DT12 Shift Actuator/Shift Controller Gasket Notice

Special Notice
When installing the shift actuator (3) and shift controller (2), please make sure to install both gaskets (1): One between the transmission housing (5) and shift actuator (3) and one between the shift actuator (3) and shift controller (2). Failure to do so will result in damage to the shift actuator (3).



13400 Outer Drive, West, Detroit, Michigan 48239-4001
Telephone: 313-592-5000
WWW.DEMANDDETROIT.COM

Specifications are subject to change without notice. Detroit Diesel Corporation is registered to ISO 9001:2008.
Copyright © Detroit Diesel Corporation. All rights reserved. Detroit™ is a brand of Detroit Diesel Corporation, a Daimler company.

18SP735 1902 As technical advances continue, specifications will change. Printed in U.S.A.