

**** SOLUTION ****

Title **Under Review Pending Upon Additional Information** Mack Chassis - Brake Lamps Do Not Illuminate During Engine Brake Activation - **US17+OBD16 and Newer Emissions**

Mack Models

Mack Model AN - Anthem , GR - Granite , PI - Pinnacle

**** SOLUTION ****

Cause Incorrect parameter value.

Solution It has been found that certain Mack vehicles brake lamps do not illuminate during engine brake activation due to an incorrect parameter value.

The programming procedure for enabling the " Brake Lamps During Engine Brake Activation " on Mack Chassis US17+OBD16 and Newer is -

1. Complete Tech Tool operation **1700 - 22 - 03 - 06** for Accessory Kit # **85150515**
2. Complete LCM software update

Internal comments (BO) Parameter Information
IVY=1
SDX=1

Solution visibility **Dealer distribution**

Function(s)/component(s) affected

Function affected MID 216 – LCM , service brake , exterior lighting

Function Group

Function Group 353 lighting, rear

Customer effect

Main customer effect calibration/programming/pairing/missing operation , visual appearance

Conditions

Vehicle operating mode deceleration , when braking

Frequency of occurrence of problem always

Administration

Author RU2761V

Dealer ID RU2761V

Last modified by A241298

Creation date 28-03-2019 17:03

Date of last update 29-05-2019 18:05

Status Published
