

Getting DTC B123F? Read This!

AFFECTED VEHICLES

Year	Model	Trim
2020	CR-V	ALL

The 2020 CR-V comes with two backup fuses: No. 18 BACK UP (10A) and No. 27 BACK UP 2 (30A). If you pull the No. 27 fuse (or it's blown), and turn the ignition to ON while leaving the No. 18 fuse intact, it will set DTC B123F (automatic lighting control unit/sunlight sensor error).

Be aware that if you find this DTC, it doesn't mean there's a hardware problem. So before you consider replacing parts, follow these steps:

1. Check the No. 27 fuse, and replace the fuse if it's missing or blown.
2. Run an ALL DTCs check.
3. Manually clear DTC B123F, and see if it comes back.
 - If the DTC doesn't come back, you're done.
 - If the DTC comes back, troubleshoot it.