

Technical Tip Train

Transaction No: 2057775/1

13-19-01TT - Rear Main Oil Seal Installation

Release date:

11/15/2019

Condition

ATTENTION:

THIS IS A TECH TIP, NOT A TECHNICAL BULLETIN.

TECH TIPS ARE NOT ASSOCIATED WITH WARRANTY CLAIMING.

Applicable Vehic	cles	3					
Model(s)	Year	Eng. Code	Trans. Code	VIN Range From	VIN Range To		
letta	2019	1.4L	ΔΙΙ	ΔΙΙ	ΔΙΙ		

Revision Table							
Instance Number	Published Date	Version Number	Reason For Update				
2057755/1	11/15/19	13-19-01TT	Original publication.				

Technical Background

Blue locking tab may not be installed to hold the crank sensor wheel in place.

It is possible the new rear main oil seal may come without the blue locking tab for the crank sensor wheel.

(DGXA, DJXA)



Note:

The engine must be set to top dead center when installing the new seal.

Service

Follow the crank sensor wheel repair manual instructions, see Repair Manual Group 13 in Elsa. Repair and relocate the crank sensor wheel to the proper location. The hole in the top of the sensor wheel should line up with the locating pin on the tool.

Additional Information

© 2019 Volkswagen Group of America, Inc. All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Volkswagen Group of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.