



Remove Top black  
Connector to  
disconnect CAN from  
the headunit.