HONDA

ServiceNews Article

April 2020

A17010C Version 3

Certain Noises After Shutting Off Engine Are Normal

AFFECTED VEHICLES

Year	Model	Trim
2017-20	CR-V	ALL

EDITOR'S NOTE: This article revises the one posted in August 2018. Changes are highlighted in yellow.

After shutting off the engine, you may hear certain noises coming from the vehicle. Here's the lowdown:

- Noise from Under Vehicle: This noise is caused by the vacuum pump inside the fuel evaporation leakage check module (ELCM). Depending on conditions, the pump will come on for about 15 minutes about 5 to 10 hours after engine shutoff.
- **Clicking from Under Hood:** This noise is caused by the electric brake booster (EBB) system. The system will come on for about **3 minutes** every time a front door is opened.

Keep in mind both of these noises are just normal vehicle operation and don't indicate a vehicle problem.