



Condition

ATTENTION:

**THIS IS A TECH TIP, NOT A TECHNICAL BULLETIN.
TECH TIPS ARE NOT ASSOCIATED WITH WARRANTY CLAIMING.**

Applicable Vehicles

Model(s)	Year	Eng. Code	Trans. Code	VIN Range From	VIN Range To
Atlas	2018-2020	3.6L (CDVC)	All	All	All

Revision Table

Instance Number	Published Date	Version Number	Reason For Update
2060260/2	7/17/20	01-20-04TT	Referral correction.
2060260/1	7/17/20	01-20-04TT	Original publication.

DTC	Description
P1640	Faulty Control Module

Technical Background

Possible P1640 fault may set after Engine-Motor Control Module -J623- replacement. This code may not be cleared from DTC memory.

Service

1. Disconnect both battery cables for 15 minutes to allow for capacitive discharge.
2. Reconnect battery cables.
3. Check DTC Engine-Motor Control Module -J623- memory.



Note:

For battery cable reconnect refer to Repair Manual Group 27 "Battery, Starter, Generator, Cruise Control" in Elsa.

Additional Information

© 2020 Volkswagen Group of America, Inc. All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Volkswagen Group of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.