Seat Heating Cannot Be Activated On Vehicles Without SA Code 275

Topic number LI91.30-P-069668

Version 2

Function group 91.30 Seat heater, seat ventilation

Date 06-15-2020

Validity Vehicles of BR 177, 118, 247 and 167 without SA code

275

Reason for change New control units available

Reason for block

Complaint:

The seat heating in the vehicle cannot be activated. When the seat heating button is pressed the 3 red LEDs light up briefly and then go off again after a brief period (approx. 3 seconds).

Cause:

To prevent too high surface temperatures on the heating surfaces (and thereby any damage to the system), the cut-in frequency of the seat heating is limited.

Consequences:

- Two-time, full operation of the seat heating results in the system's heat limit being reached (counter value in background)
- Seat heating can only be started again after a cooling-down phase (counter value must be reset to 0)
- If the vehicle is parked before resetting the value to 0, this may prevent the system from being activated the next time the ignition is operated

Remedy:

The new control units are available and can be ordered.

Replacement of the control unit is required.

<u>Variant installed in the vehicle:</u> <u>Successor control unit to be ordered:</u>

A 167 900 05 00 --> A 167 900 88 12

A 247 900 17 00 --> A 247 900 47 09

Symptoms

Body / Seat / Seat heater/comfort heater / Seat heater nonfunctional

Parts

XENTRY TIPS

Part number	ES1	ES2	Designation	Quantity	Note	EPC
A 167 900 88 12			Seat control unit	1	Predecessor: A 167 900 05 00	Х
A 247 900 47 09			Seat control unit	1	Predecessor: A 247 900 17 00	Х

Operation numbers/damage codes							
Op. no.	Operation text	Time	Damage code	Note			
			82T0D 90	Seat heating control unit, RH front seat (BR 167)			
			82E0D 90	Seat heating control unit, LH front seat (BR 167)			
			8241F 90	Seat heating control unit, front seat - MFA			

Validity						
Vehicle	Engine	Transmission				
A (177)	*	*				
B (247)	*	*				
CLA (118)	*	*				
GLE (167)	*	*				