-	ΤΟΥΟΤΑ	Tech Tip	T-TT-0616-20		ugust 19, 2020
Sen	sation or Bat			Market USA	
Service Ca	ing		Section Power Assist Sy	stems	
Applicability 2019-	, 2020 RAV4 and R	AV4 HV			
APPL	CABLE VEHICLES				
)-2020	RAV4	2019-2020	RAV4 HV	
COND	ITION				
Some			normal steering sensation ("	pulling", "drifting"). Cor	dition may
	ing Angle value dis straight.	played in Techs	tream may be greater than :	<u>+</u> 3° off when the steerin	ig wheel is
			nected or discharged, the S ero Point Calibration must b	U	Point
	e steps are consist ery Service Check		nd 4 of the "BEFORE INSP w).	ECTION" section of the	Pre-
	MMENDATIONS				
1.	Check for DTCs -	- if found, procee	ed with the repair recommer	nded in the Repair Man	ual.
2.	If no DTCs are fo	und; disconnect	the battery, wait 30 minutes	and reconnect the bat	ery.
3.	memorizing the SMemorizin	teering Angle Ne g the Steering A	heck Sheet, proceed with the eutral Point described in RM ngle Neutral Point includes: ering wheel lock-to-lock on l	1100000001FAJ7 (Link	ess for Below):
4.			gle Neutral Point (above), c Point Calibration described		
	 Steering S For Ga 	s Models: Driving	t Calibration Sequence inclu g vehicle straight at speed (vehicle straight at speed (>	>10 mph for >1 second	•
5.	After performing l steering sensatio		equences described above ected.	, confirm that the abnor	mal
6.	If abnormal opera	ation continues, c	contact TAS		
Link	References				
Expires	on 08/19/2021	Rev1 © 20	020, Toyota Motor Sales, USA		Page 1 of 2

Ver. 2.12 01/01/2020 T

ΦΤΟΥΟΤΑ	Tech Tip	T-TT-0616-20		August 19, 2020
Steering Recalib Sensation or Bat		Abnormal Steering	Market USA	
Applicability				
1_2020 R	AV4. RAV4 HV Pr	e-Delivery Service (PDS)	Check Sheet	
2. <u>PRE-C</u>		OLLISION SYSTEM: INI		<u>9 - 2020 MY</u>

3. PARK ASSIST / MONITORING: PARKING ASSIST MONITOR SYSTEM: INITIALIZATION; 2019 - 2020 MY RAV4 RAV4 HV [11/2018 - ??????]

Expires on 08/19/2021