

Problem: CHECK FURNACE FAN RUNS BUT NOT LIGHTING. Cause: Heater not working. Correction: Pulled heater from unit bench test shows bad (sail switch)sensor switch need new. Please contact Atwood for warranty part and labor.