

scr conversion codes only when...



[Engines Service](#) 3 posts since Nov 18, 2014

scr conversion codes only when bobtailing Feb 12, 2021 4:11 PM

anyone have dd15 causing scr codes while bobtailing, yet no problems with a load, customer also complains about engine temps lower when bobtailing? vin ku7344



[Scott Trippel](#) 4,094 posts since Dec 13, 2014

Re: scr conversion codes only when bobtailing Feb 12, 2021 10:08 PM

These things can have conversion faults in different duty cycles.

What have you found when troubleshooting the code.

What does the log file show when in bobtail mode, specifically what is the inlet and outlet nox values. I am sure this is where you will need to start.



[Steve Reppard](#) 168 posts since Jun 29, 2020

Re: scr conversion codes only when bobtailing Feb 16, 2021 4:03 PM

What t/s have you done with results? These conversion codes can be very complexed so to be of any help we need to know details.