

Normal Functionality For Vehicles Built Without Door Unlock Sensor And/Or BCM Software To Support Door Unlock Sensor

For Applied Vehicles built after the Applied Dates listed on page 1, using the mechanical key on the driver door will operate differently than vehicles built before the Applied Dates.

For these later models, the **BCM will not recognize operation of the mechanical key.**

If a mechanical key is used to **lock** the driver door.

- The security system will not set. If the vehicle is broken into, the alarm will not sound.
- Only the driver door will be locked. Other doors will not lock using the mechanical key.

If a mechanical key is used to **unlock** the driver door.

- Only the driver door will be unlocked. Other doors will not be unlocked.
- If the security system is set, when the door is opened the alarm will sound.

NOTE: Using the Unlock button on the Intelligent Key, pushing the request switch on the driver or passenger door with the Intelligent Key in range, or using the Intelligent Key to start the vehicle will silence the alarm.

The mechanical key will not operate the power windows.

AMENDMENT HISTORY

PUBLISHED DATE	REFERENCE	DESCRIPTION
October 22, 2018	NTB18-071	Original bulletin published
February 9, 2021	NTB18-071a	Classification number updated