
PuMA measure

SVA infotext in instrument cluster / SVA can now be deactivated

US 64481126-01 - 4/29/21

Complaint:

SVA! infotext is displayed in instrument cluster (see attachment)

Cause

SVA - Side View Assist is deactivated.

Measure

SVA can be deactivated in the instrument cluster starting with programming I-level K001-18-07-500.
It is displayed as SVA! in the instrument cluster to indicate that SVA is deactivated.
This function is explained in the new Owner's Handbook. Please advise customers.

Validity information

Model series:	[K19]
Engine range:	[ALL]
Body style:	[ALL]
Fault codes:	[]
Production period:	-

Repair overviews

Attachments

Number of attachments: 1