



Front wheel hub spigot clicking noise on conventional & Light-weight Discs.

Remove corrosion from wheel hub spigot



Apply- MOLYKOTE® Cu-7439 Plus Paste to wheel hub spigot area as below



Apply onto the wheel hub inner annulus hub face.

