

Instrument Cluster warnings when Driver's door opened

Topic number	LI80.57-P-073748
Version	1
Function group	80.57 - Drive authorization system (DAS)
Date	10/12/21
Validity	Model series 206 and 223
Reason for change	

Complaint

Red steering wheel symbol and error messages about non-functional parking brake, non-functional traffic sign assist and restraint system malfunction are displayed in the instrument cluster after opening the driver's door. The error messages are no longer displayed after ignition "ON".

The problem can be duplicated as follows:

- Lock vehicle
- Waiting time > 8 minutes
- Unlock vehicle
- Open driver's door

Note: The errors displayed in the instrument cluster have no impact on the vehicle's functions.

Attachments	
File	Description
Beispielvideo.mp4	

Cause

Due to a hardware fault in the EZS, there is a problem with starting up the FlexRay communication when opening the driver's door after the vehicle was in bus idle. When the ignition is then switched on, the FlexRay communication is restarted and functions properly.

Remedy

Replace electronic ignition switch.

Symptoms
Body > Safety system > Airbag/Supplemental restraint system SRS > Indicator lamp > SRS indicator lamp > lit
Chassis/suspension > Steering system > Display message > Pow. steer. faulty Serviced Required
Chassis/suspension > Brake system > Parking brake > Display message > Parking brake - Parking brake see Owner's Man.

XENTRY TIPS

Operation numbers/damage codes				
Op. no.	Operation text	Time	Damage code	Note
			8000NEC	