

2021 Plateau

Procedure to insert the control switch back:

1. Looking at the left side of the control switch there is a tab. (picture 1 below)
2. Insert the whole control switch back to the cut out hole
3. On the inner side of the screen inside coach, using a screw driver push the control switch tab to the right so the control switch locks in place (picture 2 below)

