

The driver's side window is failing. The jalousie arm on the front lower window fails to align. The plastic wheel guide on the jalousie arm wheel is broken off. Tech tried putting back together several times, but window still will not close properly.

1. Close window.
2. Use 9/64 drill bit to remove 2 rivets on right top side of window.



3. Push gently horizontal bar down about 1 ½ inches until you see arm is lower than wheel track. Swing the arm until its lined up with the wheel track.



4. Insert wheel inside track then push horizontal bar up and put 2 new rivets. Touch up rivets with black paint/marker.