

## After starting the engine, the instrument cluster shows the "EBD not available, diagnosis/test stand" message in yellow

---

Topic number	LI42.45-P-073405
Version	1
Function group	42.45 - Electronic stability program (ESP)
Date	8/2/21
Validity	Model series 204 facelift and R172
Reason for change	

---

### Complaint

After starting the engine, the instrument cluster shows the "EBD not available, diagnosis/test stand" message in yellow.

#### Note:

The road test was not activated by the workshop and therefore the workshop cannot deactivate it using the necessary driving maneuver.

#### Note:

In the ESP control unit (N30/4 - ABR2XT) the DTC (fault code) C141000 "Road test is active" is a current entry.

No other fault codes are present in the ESP control unit.

### Cause

Drive test is active.

### Remedy

Deactivation of active drive test through a password-protected routine in XENTRY.

The system involved means that this password is only valid for a few days and it is VIN/FIN specific, and therefore a PTSS case must be created for each vehicle.

Symptoms
Chassis/suspension > Brake system > Brakes/traction regulation system > Brake assist system BAS > Display message > Brake assist - not available
Chassis/suspension > Brake system > Brakes/traction regulation system > Brake assist system BAS > Indicator lamp > Goes on

# XENTRY TIPS

---

Chassis/suspension > Brake system > Brakes/traction regulation system > Anti-lock brake system (ABS) > Display message
Chassis/suspension > Brake system > Brakes/traction regulation system > Anti-lock brake system (ABS) > Indicator lamp on
Chassis/suspension > Brake system > Brakes/traction regulation system > Electronic Stability Program (ESP) > Malfunction
Chassis/suspension > Brake system > Brakes/traction regulation system > Electronic Stability Program (ESP) > Display message
Chassis/suspension > Brake system > Brakes/traction regulation system > Electronic Stability Program (ESP) > Indicator lamp
Chassis/suspension > Brake system > Brakes/traction regulation system > Anti-slip control > Malfunction
Chassis/suspension > Brake system > Brakes/traction regulation system > Anti-slip control > Indicator lamp
Communication/information > Information display > Indicator lamp > Malfunction
Communication/information > Information display > Indicator lamp > lit

## Control unit/fault code

Control unit	Fault text
N30/4 - Electronic stability program (ESP®)	C141000 - The road test is active.

## Operation numbers/damage codes

Op. no.	Operation text	Time	Damage code	Note
---------	----------------	------	-------------	------