



STAR ONLINE PUBLICATION



Case Number: S2108000163

Release Date: July 2021

Symptom/Vehicle Issue: No Start, Cannot Complete Module Replace, Proxi Or Module Proxi Configuration

Technician Observation: Module replacement requirements cannot be completed.

Repair Procedure: When replacing any module and or multiple modules at the same time, follow the 08-Electrical/8E Electronic Module Replacement Guide/ Standard Procedures for the most current MISC function and priority steps to successfully align and replace a module(s).

Example: 2018 Renegade BCM Replace

08 - Electrical / 8E - Electronic Control Modules / Standard Procedure MODULE REPLACEMENT GUIDE (RF-HUB, PCM, BCM, ESL)

COMPONENT	Condition 1	Condition 2	Condition 3
RFH	New	Existing	Existing
FOBIKs (RKE Only)	Existing	New	Existing
BCM	Existing	Existing	New
PCM	Existing	Existing	Existing
ESL	Existing	Existing	Existing
PROGRAMMING ORDER			
1	RFH replacement	Enable KEYS/FOBIKs (Only the new FOBIK needs to be present, previously stored FOBIKs will remain enabled.)	BCM replacement
2	Disable KEYS/FOBIK (Only if the procedure not run automatically after the RFH replacement procedure. All FOBIKs should be present, but the FOBIKs not present at this time will be temporarily disabled. It will be possible to re-enable them by running the Enable KEYS/FOBIKs procedure.)	---	Run BCM ECU Reset (Found under the Diagnostic Procedures Tab of the Vehicle View screen)
	RFH TPM Update		

2. Run BCM ECU Reset

This document does not authorize warranty repairs. This communication documents a record of past experiences. STAR Online does not provide any conclusions about what is wrong with the vehicle. Rather, it captures all previous cases known that appear to be similar or related to the vehicle symptom / condition. You are the expert, and you are responsible for deciding on the appropriate course of action.

Contact STAR Center, or your Technical Assistance Center Via TechCONNECT or eCONTACT ticket if no solution is found