

Seat Heating Does Not Get Warm (LEDs Light Up)

Topic number	LI91.30-P-073902
Version	1
Function group	91.30 - Seat heater, seat ventilation
Date	12/9/21
Validity	Model series 205, 253 WITHOUT Memory Package (code 275)
Reason for change	

Complaint

Seat heating on driver's seat and front passenger seat nonfunctional.

The LEDs on the switches for the seat heating illuminate, but the seat heating mats do not get warm.

Cause

Faulty SCN coding of rear SAM.

Remedy

- Perform SCN coding of rear SAM (BC_R).
- Commission seat heating control unit.

Symptoms
Body > Seat > Seat heater/comfort heater > Seat heater nonfunctional

Operation numbers/damage codes				
Op. no.	Operation text	Time	Damage code	Note
			54590F1	