

## QUARANTINE NOTICE

<b>Reference number:</b>	QN-01-1593	<b>Issued: 04 February, 2022</b>
<b>Subject:</b>	Vantage Swing Clearance Check	
<b>Model(s):</b>	Vantage	
<b>VIN Range:</b>	Refer to the separately published list of affected Vehicle Identification Numbers (VINs)	
<b>Applicable to:</b>	All Dealers	
<b>Distribute to:</b>	<b>After Sales Manager</b> <b>Executive Manager</b> <b>Service Manager</b> <b>Sales Manager</b>	<b>Warranty Staff</b> <b>Technician(s)</b> <b>Parts Staff</b>

### Reason for this Quarantine Notice

Aston Martin has identified some Vantage vehicles that must have a swing clearance check completed to make sure the doors have the correct clearance when opened.

Do the workshop procedure that follows to do a swing clearance check of the doors, and if necessary complete the applicable adjustment procedure.

### Workshop Procedure

1. Do a swing clearance check of the doors (refer to Workshop Manual Procedure 00.10.DF).
2. If adjustment is not necessary, no further action is necessary.
3. If adjustment is necessary, refer to the applicable adjustment procedure in the workshop manual.

### Warranty Data

*Note: Before the warranty repair is started, photograph the affected area(s). The photograph(s) must be attached to the repair order for audit purposes.*

#### Tier A

Description	Labour Time
Swing Clearance Check	0.10

#### Tier B

Description	Labour Time
Check Clearance and Adjust Bonnet	0.40

#### Tier C

Description	Labour Time
Check Clearance and Adjust 1 Door	1.8

**Tier D**

Description	Labour Time
Check Clearance and Adjust Both Doors	3.5

**Tier E**

Description	Labour Time
Check Clearance and Adjust 1 Wing	0.45

**Tier F**

Description	Labour Time
Check Clearance and Adjust Both Wings	0.80

**Tier G**

Description	Labour Time
Check Clearance and Adjust 1 Door and 1 Wing	2.15

**Tier H**

Description	Labour Time
Check Clearance and Adjust 1 Door and Both Wings	2.50

**Tier I**

Description	Labour Time
Check Clearance and Adjust Both Doors and 1 Wing	3.85

**Tier J**

Description	Labour Time
Check Clearance and adjust both Doors and both Wings	4.2

**Tier K**

Description	Labour Time
Check Clearance and Adjust Bonnet and 1 Door	2.1

**Tier L**

Description	Labour Time
Check Clearance and Adjust Bonnet and Both Doors	3.8

**Tier M**

Description	Labour Time
Check Clearance and Adjust Bonnet and 1 Wing	0.75

**Tier N**

Description	Labour Time
Check Clearance and Adjust Bonnet and Both Wings	1.1

**Tier O**

Description	Labour Time
Check Clearance and Adjust Bonnet, 1 Door and 1 Wing	2.45

**Tier P**

Description	Labour Time
Check Clearance and Adjust Bonnet, 1 Door and Both Wings	2.8

**Tier Q**

Description	Labour Time
Check Clearance and Adjust Bonnet, Both Doors and 1 Wing	4.15

**Tier R**

Description	Labour Time
Check Clearance and Adjust Bonnet, Both Doors and Both Wings	4.5

Yours faithfully



John Cranfield

Senior Manager - Client Technical Services

If you have any questions related to this document, please refer to the 'Contact Us' link on this webpage, or contact your local Dealer or After Sales Manager.

The English version of this document is written in Simplified Technical English to ASD-STE100™.