



TECHNICAL TOPICS

BODY/CHASSIS



2 nd Row Seat Deployable Heel Rest Lower Level Assembly	17MY-Onwards Range Rover
<p><u>Customer Voice:</u></p> <ul style="list-style-type: none">A customer may report that the heel rest for the 2nd row executive seats is not operating properly. <p><u>Technical Description:</u></p> <ul style="list-style-type: none">This may be caused by a heel rest motor malfunction or damage to the heel rest frame. <p><u>Status:</u></p> <ul style="list-style-type: none">The heel rest motor and frame have now been released as a lower level service part, preventing the need to replace the front seat back frame assembly to service the heel rest motor or frame.Please refer to the lower level assembly service parts to conduct repairs wherever possible upon diagnosis of a heel rest motor or frame failure.The service procedure has been added to the Workshop Manual, section 501-10: Seating > Removal and Installation > Front Row Passenger Seat Heel Rest Motor And Mechanism.	  <p>Exploded view diagram of the heel rest lower level assembly. Key components and part numbers shown include: HC1, <65500D, <42456, HS1, HN1, <618K88, HN2, <61018, <111A74, <600E22, 5011010, 12-2021, LAK, C0280790-05, <2532, 19D603B, 19D603C, and 19D603A. A blue circle highlights the motor and frame assembly.</p> <p>© Copyright 2021, Jaguar Land Rover Limited.</p>

